HUDSON VALLEY
LIGHTING GROUP

HUDSON VALLEY LIGHTING | TROY | CORBETT
MITZI | SCHOOLHOUSE | SONNEMAN | CSL

Care, Maintenance & Cleaning Instructions

TURN OFF AND UNPLUG ANY FIXTURE BEFORE YOU START TO CLEAN IT.

Lamps: All lamps should only be wiped clean with a dry soft cloth.

Finishes: To avoid damage to the finish do not use the following: polish, cleaners, soap, abrasives or chemicals. Using any of the mentioned cleaning methods will void the product warranty. Aged Brass (AGB) fixtures should be handled with clean hands or gloves to avoid leaving fingerprints.

Fabric Shades: Use a Dry Cleaning Pad (rubgum, draftsman) to clean the shade. For a deep clean, the shade can be vacuumed when dusty, by using the appropriate attachment with very soft bristles. Or take a soft brush and begin to brush off the dust. Do both methods in long, smooth strokes from the top of the shade to the bottom. Remember to clean the inside of the lampshade as well.
Note: Avoid using a brush or a vacuum attachment if you notice any rips or tears in the fabric. Using any different method will void the product warranty.

Acrylic Diffusers: Do not clean with ammonia base cleaners (e.g. Windex®), polish, cleaners, soap, abrasives or chemicals. Use only water or cleaners specifically formulated for cleaning plastics. Always use a soft cloth. Never use a dry cloth or your hand to clean your acrylic. Using any of the mentioned cleaning methods will void the product warranty.

Any Wood Pieces: Clean with a soft, damp cloth. Use mild soap if necessary and dry immediately. Avoid household cleaners and abrasives.

Textiles, Rugs: Shedding of loose fiber may occur and will lessen with regular cleaning. Do not pull loose ends, instead clip with scissors to remove. Shake or vacuum as needed. Its preferable to use a vacuum cleaner without a beater bar. When adjustable, set beater bar to the highest pile setting and set power to low. Vacuum full length of rug, rather than back and forth motion. Clean spills immediately by blotting with a clean sponge or cloth. Professional rug cleaning recommended. Harsh chemicals and direct sun exposure may damage or fade rug. Use rug protectors under furniture. Rug pad recommended for use on hard floor.

Textiles, Bedding: Machine wash cold with similar colors, no bleach, tumble dry low and remove promptly, low iron.

Hardware: Clean with a soft, damp cloth. Liquid dishwashing soap if needed. Do not use abrasive or solvent-based cleaners.







TOP TO BOTTOM:
Issa Wall Sconce, Mitzi | Design, Curated Nest
Leetown Table Lamp, Hudson Valley Lighting | Design, Currated Nest
Evelyn Table Lamp, Schoolhouse

Revised 06/25/2026